

## Silicone Roof Coating Restoration (RCR) System over Gravel BUR

# **Installation Overview**

**Note:** The following instructions are an overview of the Silicone Roof Coating Restoration installation process; they are not intended to replace the Recommended Design Specifications found at PMsilicone.com.

#### **Cleaning:**

- 1. Remove all loose stone by power broom or vacuum.
- 2. Powerwash entire roof surface and all other areas to receive new coating.
- 3. Spray apply P-160 Asphalt Bleed-Block Primer over entire roof area at a rate of 1 gallon per square.

#### **Surface Prep:**

- 4. Roof areas greater than 500 square feet containing moisture below the roof surface need to be replaced.
- 5. Roof areas less than 500 square feet containing moisture below the roof surface need to have a moisture relief vent installed.
- 6. Any flashings that do not provide a watertight condition receive a 3 course coating-fabriccoating detail.
- 7. Repair or replace any sheet metal that does not provide a watertight condition.

### **Surface Leveling Coating Installation:**

- 8. Spray apply SL 800 Surface Leveling Coating at a rate of 3 to 6 gallons per square, depending on surface texture.
- 9. After applying SL 800, there should be no rock protruding more than a maximum of <sup>1</sup>/<sub>4</sub>" out of the coating.
- 10. Allow coating to fully cure for 1 to 2 days, depending on environmental conditions.

#### **Coating Installation:**

- 11. Ensure the surface is completely dry.
- 12. Install silicone in two passes to achieve a total thickness of:
  - a. 30 mils minimum for a 5 year warranty
  - b. 35 mils minimum for a 10 year warranty
  - c. 40 mils minimum for a 15 year warranty
  - d. 45 mils minimum for a 20 year warranty